

ALTERNATOR TRUCKS OLD GENERATION

UNIT	ALTERNATOR	DIODES BRIDGE	BEARING FRONT	BEARING REAR	REGULATOR & BRUSH	OBSERVATION
SUPRA 422 AI	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 422	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 322	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 444	30-60050-07	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 450	30-60050-07	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 522	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 544	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 550	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 722	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 744	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 750 / 750 SWAP	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 750 MT	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 822	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 844	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 850	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 850 MT	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 850U ETO	30-60050-04 add pulley 4PK P/N: 50-60344-00	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 850U APO	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 922 ETO	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 944 ETO	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 944U / 988U	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 950 / 950U	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
SUPRA 950 MT	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
SUPRA 950U MT	30-60050-08 add pulley 6PK P/N: 50-60261-00	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
OASIS 100 / 150	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
OASIS 200 / 250 / 250MT°	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
OASIS 300 / 350	30-60050-04	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 70A
GENESIS R70	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
GENESIS R80	30-60050-08	30-60050-22	04-60008-19	04-60008-04	30-60050-20	
GENESIS R90	30-60050-03	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A
GENESIS R90U	30-60050-08	30-60050-22	04-60008-19	04-60008-04	30-60050-20	14V 50A

**Be Careful, some alternators used always the old version of diodes bridge P/N: 30-60050-21, please use diodes bridge 30-60050-21 only for alternators :
P/N: 30-60050-00 / -01 / -02 and -05**

**Reminder: 30-60050-00 replaced now by 30-60050-03 30-60050-02 replaced now by 30-60050-04
 30-60050-01 replaced now by 30-60050-06 30-60050-05 now NLO**

UNIT	ALTERNATOR	BEARING (front, rear)	ROTOR	STATOR	RECTIFIER NEGATIVE	RECTIFIER POSITIVE	BRUSHES	REGULATOR
SUPRA 922 NAO	30-00409-65	30-00409-51	30-00409-41	30-00409-42	30-00409-56	30-00409-55	30-00409-30	30-00409-44
SUPRA 944 NAO	30-00409-65	30-00409-51	30-00409-41	30-00409-42	30-00409-56	30-00409-55	30-00409-30	30-00409-44