

ZEPHYR 20S / 30S					
UNIT	Micro	Micro Reman	Cab command	Cab command / micro cable	Sensor RAS
Z20S / Z30S	12-60029-23	Not available	79-60409-00	22-60168-04 10m 22-60551-05 13m 22-60551-07 16m	22-60167-01 (with 2 wires)
Z30S road starting with S/N PB 225225	12-00511-50 (all option grey box) micro with connector	Not available	79-60409-00	22-60551-04 10m 22-60551-05 13m 22-60551-07 16m	12-00512-10 (with 2 wires)
Z30S road starting with S/N : PB413071	12-00511-51 (all option grey box) micro with connector	Not available	79-60409-00	22-60551-04 10m 22-60551-05 13m 22-60551-07 16m	12-00512-21 (with 3 wires)
Z30S road starting with S/N : PB530101	12-00511-52 (all option grey box) micro with connector	Not available	79-60409-00	22-60551-04 10m 22-60551-05 13m 22-60551-07 16m	12-00512-21 (with 3 wires)
INTEGRA 20S					
UNIT	Micro	Micro Reman	Cab command	Cab command / micro cable	Sensor RAS
Integra 20S	12-60029-18	Not available	79-60409-00	22-60551-04 10m 22-60551-05 13m 22-60551-07 16m	22-60167-01 (with 2 wires)
ZEPHYR 300 (micro)					
UNIT	Micro	Micro Reman	Cab command	Cab command / Micro cable	Sensor RAS
Z300 12v	12-60029-17	Not available	79-60409-00	22-60168-04 10m 22-60551-05 13m 22-60551-07 16m	22-60167-01 (with 2 wires)
Z300 24v	12-60029-20	Not available	79-60409-00	22-60168-04 10m 22-60551-05 13m 22-60551-07 16m	22-60167-01 (with 2 wires)
Z300 12v B T°	12-60029-15	Not available	79-60409-00	22-60168-04 10m 22-60551-05 13m 22-60551-07 16m	22-60167-01 (with 2 wires)
Z300 24v B T°	12-60029-19	Not available	79-60409-00	22-60168-04 10m 22-60551-05 13m 22-60551-07 16m	22-60167-01 (with 2 wires)